

VINTAGE Wall coverings

Installation guide



Material and tools required

- Construction glue PL type
- Caulking gun
- Finish nailer
- Finishing nails (#18 nails)
- Step ladder
- Miter saw
- Table saw
- Level
- X-Acto typing knife
- Measuring tape

Expect a 5% cutting loss when buying your wall coverings.

Always wear work gloves and safety glasses when installing the product.

PREPARATION

Make sure that ambient humidity in the room that you decided to install your wall coverings ranges between 35% and 55% inclusively. Maintain this ambient humidity before, during and after the installation work. If the humidity degree is not respected, this would invalidate the InnoveX Wood warranty.

The wood should first acclimatize to the room temperature 48 to 72 hours before installation.

Before starting installation, make sure that the wall is clean to allow glue to adhere well. It is important to ensure that the wall(s) is level from floor to ceiling. If not, adjust accordingly because the wall coverings will not correct or pronounced defects of the wall. With the nature of the wood, it is possible that the angle has to be slightly corrected at the installation.

INSTALLATION

STEP 1:

Open all the boxes and take out the planks. Make sure to select the planks according to the color variation and choose where you want to install each of them to obtain the desired results. If some planks are damaged, put them aside to be used for cuts.

STEP 2:

Install the appropriate mouldings if desired (casings, plinths, "L" mouldings).

STEP 3:

Draw a level line on the wall at the top of the first plank. Apply some dye on the apparent cut if necessary.

STEP 4:

Spread 2 lines of glue behind the plank and fix it to the wall by applying pressure. With the finish nailer, fix 2 nails per plank.

STEP 5:

Always verify the level of each row and adjust if necessary.

Note for the installation of the Chevrons wood:

Call a qualified professional for the installation of chevrons wood.

To comply with our warranty policy, visit www.innovexwood.com